

Eazyfile

Instructions



View instructional video here: <https://youtu.be/NxihUQFiCIY>

Thank you for purchasing our Saturn Eazyfile, we hope you enjoy the benefits of using this product.

How the Eazyfile works.

The Eazyfile uses a continually rotating nail file belt traveling across opening at the front of the Eazyfile, you can see or feel where you need to press the nail up against the rotating file belt and watch or feel the nail being filled with ease. It is here at the front opening where you can replace the file belt, follow the file belt replacement instructions.

IMPORTANT: The Eazyfile is not a toy, but is a hygiene product and therefore should be for personal use only.

When using the Eazyfile correctly and regularly, you will never need to use scissors or nail clippers on your nails again.

Operation:

- The Eazyfile requires 2 x AA batteries (not included) you will require a small cross head screwdriver to remove and refit the battery cover.
- The Eazyfile will come with a Grade 1 Saturn smooth file belt fitted ready for use. A further 2 file strips are included within the box. 1x Grade 2 file strip and 1x Grade 3 file strip (you can purchase further Saturn white gold file strips from our website, eazyfile.co.uk)
- To start the file belt rotating, press down the on/off button on the top of the unit. For safety reasons, the file belt will only rotate when holding the button down.

The Saturn Eazyfile is suitable for:

- Finger and toe nails only
- Use of children from the age of 5 years and over.
- Used on children under the age of 5 years old
- For male and females
- For anyone who can't cut or clip their nails due to certain conditions such as diabetics etc.
- For anyone with poor or no eyesight.
- For anyone with poor hand movement such as arthritis or elderly and frail.
- Or for children who are too young to cut or clip their own nails.

Warning: This device is intended only for filing human finger and toenails, avoid use on irritated, ingrown, or infected finger or toenails, consult a physician before use if any nail conditions exist, Do not rinse the eazyfile with water or any other liquid. Only clean the outside of the unit with a soft, dry cloth, damaged or malfunctioning, discontinue use immediately.

When using the Eazyfile you should:

- Use only on finger and toe nails
- Use as directed within these instructions
- Use if or when the finger or toe nail requires shortening or maintaining

- Use only in a dry environment
- Supervise children under the age of 6 years old
- For best results use the graded file strip/belt that best suits your requirements” the grade 1, 2 or 3 is written on the reverse side of the file strip”
- When replacing the file belts follow the “file belt replacement instructions” carefully.

DO NOT:

- Do not use in wet or damp environment i.e. in the bath, shower or outdoors when raining etc.
- Do not allow the belts or inside of the unit become oily, greasy or wet, see (file belt replacement instructions)
- Do not operate in temperature conditions below 5 °c or above 40 °c
- Do not drop onto hard surfaces from any height, avoid dropping altogether
- It’s not advised that you share the Eazyfile with others as this is a hygiene product and by doing so could risk passing on fungal nail infections etc.
- Do not use if the eazyfile becomes damaged or is malfunctioning, discontinue use immediately,

The file Belt Change

View belt change video here: <https://youtu.be/G3PyYoFoozU>

Changing the belt is very easy, all you need to do is follow these 6 simple steps below or follow this link to watch our short File belt change video ...video link coming soon.....


1. Pull and unclip the black belt guard from the front of the eazyfile
2. Either cut with scissors or tare the old used file belt.
3. Activate the power button on the top of the eazyfile, this will eject the used belt.
4. Take your chosen grade file strip in your right hand, hold the easyfie in your left hand. With the grit facing out and instructions facing in, feed in the strip with the peel away tab first into the right side of the eazyfile between the 3rd roller on the right and the body of the unit. Feed the belt in until you feel it stop, then activate the power button and this will draw the file strip through the eazyfile. (instructions are on the reverse side of the file strip)
5. When both ends of the file strip are exposed on both sides of the front opening you can gently pull either end of the strip to align them so that they are even lengths.
6. Holding the eazyfile with both hands looking in to the front of the unit, peel away the easy peel tab which should be on the left-hand side, avoiding touching the glue press the file strip firmly down against the curved wall and up against the top line.

With your right thumb push the right-hand strip firmly over the middle-curved roller and press the end firmly down on top of the glued end.

IMPORTANT NOTICE


Before closing the 2 ends together ensure they look ready to line up together and are strait and level with each other. If they do not line up strait or closed tight enough the newly formed file belt will not work properly and once the ends are made they are fixed for good. If this occurs and file belt is not rotating properly you will need to load in a new file strip.

ATTENTION: Please follow user instructions before use.




DO NOT MISALIGN BELT JOIN

2



DO NOT LEAVE ANY GLUE EXPOSED

2



MAKE SURE BELT IS LEVEL AND TIGHT

2

Environment

Please consider the environment when disposing of used Batteries, Belts and your eazyfile unit.



Do Not dispose of batteries in the bin



Recycle damaged, unwanted or life expired eazyfile unit at your local recycling centre



Dispose of used belts and packaging in the correct recycling bins.