

Saturn Eazyfile

Maintenance



View maintenance video here: <https://youtu.be/rTUB2jfVtYY>

Maintaining the Eazyfile is very easy. all you need to do is follow these 5 simple steps below or follow this link to watch our short maintenance video ...video link coming soon.....

1. Each time you change the file belt you should clean the internal rollers.
2. Using the old used file belt that you have removed, place the used strip under clean running water for approximately 2 seconds until completely wet.
3. Shake the strip off to rid it from excess water and then feed into the unit as if you were loading a new strip.
4. Press and continue to hold the power button down and at the same time hold the right-hand side of the strip between your finger and thumb. Then allow the strip to be drawn into the unit up as far as your grip but resist its pull and slowly pull the strip back completely out of the unit. You will feel the unit fighting against you, but this is fine. This single action will have cleaned the internal rollers. You will only need to do this once. Do not continue this action as the belt may become weak and snap inside the unit.
5. Allow the unit to dry for about 5 minutes before loading the new file strip, following the belt change instructions.

ATTENTION: Please follow user instructions before use.